

THE NEWGREN COMPANY

PARTS AND SERVICE BULLETIN


SUBJECT: HYDRAULIC LINKAGE

NO. 6
DATE May 21, 1947

The success of the "pump drive" is based upon careful installation and adjustment. Particular care should be shown to the following two points:

1. Special crankshaft nut must be installed tight and have two small Allen screws definitely indexed into holes drilled in pump pulley.
2. Alignment of pump drive to rubber disc and crankshaft nut so that no decided vibrations are noticeable.

Yours very truly,



Hugh Dorman
Sales Department

HD:EMG

Please route copies to:

Office.....

Parts Dept.....

Service Dept...